

WATERMAN CARIBBEAN (SCORESBY) — GROUND

44 Lakeview Drive, Scoresby 3179

LEVEL — GROUND



LEGEND

- Fire Extinguisher
- Fire Blanket
- Fire Hydrant
- Emergency Phone
- Fire Hose
- Fire Indicator Panel
- Manual Call Point
- Emergency Exit



In case of emergency, please call 000

WATERMAN CARIBBEAN (SCORESBY) — LEVEL 1

44 Lakeview Drive, Scoresby 3179

LEVEL — ONE



LEGEND

- Fire Extinguisher
- Fire Blanket
- Fire Hydrant
- Emergency Phone
- Fire Hose
- Fire Indicator Panel
- Manual Call Point
- Emergency Exit



In case of emergency, please call 000

WATERMAN CARIBBEAN (SCORESBY) — LEVEL 2

44 Lakeview Drive, Scoresby 3179

LEVEL — TWO



LEGEND

- Fire Extinguisher
- Fire Blanket
- Fire Hydrant
- Emergency Phone
- Fire Hose
- Fire Indicator Panel
- Manual Call Point
- Emergency Exit



In case of emergency, please call 000









WATERMAN CARIBBEAN (SCORESBY) — LEVEL 3

44 Lakeview Drive, Scoresby 3179

LEVEL — THREE



LEGEND

-  Fire Extinguisher
-  Fire Blanket
-  Fire Hydrant
-  Emergency Phone
-  Fire Hose
-  Fire Indicator Panel
-  Manual Call Point
-  Emergency Exit



In case of emergency, please call 000